



Einhell



FREELEXO CAM



INSTALLATIONSVIDEO D:
<http://qr.einhell.com/3bde0669>






INSTALLATION VIDEO GB:
<http://qr.einhell.com/3bdf066a>








1






2




3



4




5



1
ON

2




3



4



6



1

4H₁

6H₂

8H₃

10H₄



OK

START
A/B

2

PIN:
1-2-3-4
→ OK

4H₁

6H₂

8H₃

10H₄



OK

START
A/B

3

HOME

4H₁

6H₂

8H₃


10H₄












OK

START
A/B

4



7



CHECK



4H₁

6H₂

8H₃

10H₄





OK

START
A/B

1

START
A/B

2



8

4H₁

6H₂

8H₃

10H₄




OK

START
A/B

1



2



CHECK